



PARTS LIST

Reference	Qty	Description	Reference	Qty	Description
A	(4)	61-1/4" Tube	1	(2)	10-8 Kee Klamp
B	(10)	61-1/4" Tube with swag	2	(2)	15-8 Kee Klamp
C	(3)	20-1/2" Tube	3	(2)	25-8 Kee Klamp
D	(2)	12" Braces	4	(2)	12-8 Brace Fitting

Qty	Description	Qty	Description
(3)	2" i.d. PVC ground sleeves	(1)	Vinyl Skirt
(1)	Pole Cap	(10)	Release Ty-raps
(1)	Rebound Net	(1)	Webbing Strap
(30)	Bungee Cords	(1)	Set Screw Key
(20)	Adjustable Straps		



1. Sink PVC sleeves to a depth of 2' in concrete at least 3' deep, as shown in the illustration. Note that the center pole is set back from the (2) end poles.
2. Assemble the bottom bar over the holes as a guide. Lift off, lay down, and finish assembly of the frame on the ground. Use the set screw key to secure poles in fittings. Be sure the whole frame, including the 1' setbacks, is assembled before installing the net.
3. To install the netting, hook and fasten the bungee cords evenly along the sides and top of the frame. Evenly space and tighten the 20 adjustable straps along the bottom of the netting.
4. Attach the vinyl skirt at the bottom using ty-raps. Thread white webbing into the netting at the desired location to simulate net height.